



Milesight-Troubleshooting Motion Detection on NVR

IP Camera Version	xx.5.0.104	NVR Version	xx.7.0.01	Update	2015.11.26
--------------------------	-------------------	--------------------	------------------	---------------	-------------------

To help you to get the points you want, please read the lead-in first.

Lead-in

This document is organized by the order below:

1. How to Enable the Motion Detection
 - 1)Way one--enable the motion detection via NVR
 - Local monitor setting
 - Web interface setting
 - 2)Way two--enable the motion detection via IP cameras
2. Recording Setting for Motion Detection
 - 1)Local monitor setting of recording
 - 2)Web interface setting of recording
3. Other Alarm Actions for Motion Detection
 - 1)Local monitor setting of other alarm actions
 - 2)Web interface setting of other alarm actions

Note:

- The 1. is the first step and the basic of 2. and 3.. If you want to record video when motion detection is triggered, please refer to 1. and 2.. If you want to hear audio alarm or set other alarm actions when something moves in the detected region, please refer to 1 and 3..
- Please attach importance to where the mark **** appears, because it may removes your confusions or give a quick guide when you operate the motion detection of NVR.

1. How to Enable the Motion Detection

Milesight's NVR and IP cameras are data synchronization in the terms of motion detection; hence you can just choose one of two ways below, via NVR or via IP cameras, to enable it.

1) Way one--enable the motion detection via NVR

- Local monitor setting

Step1: Log in the local monitor, and go to “Event”→“Motion Detection”



Figure 1.1 Motion Detection Settings in Local Monitor

Step2: Choose the corresponding channel, set the motion region and motion sensitivity.

Step3: As for the schedule of motion detection, if you tick the “Enable camera’s Motion”, the schedule will be set as continuous type, whole day and whole week. If not, the schedule is decided by settings of IP cameras. **So the schedule setting of motion detection on cameras must be done before if you don’t tick this option or you want to set detection for a certain time.**

Step4: Check settings. Log in “Status”→“Event Status”, when something moves in the detected region, we will see the “” changing to “”, besides there is a motion indication “” in local monitor live view.




Figure 1.2 motion detection status in NVR local monitor

- Web interface setting

Step1: Log in NVR Web, click “Settings”→“Event”→“Motion Detection”.




Figure 1.3 Motion Settings in NVR Web

Step2: Choose the corresponding channel, set the motion region and motion sensitivity.

Step3: As for the schedule of motion detection, if you tick the “Enable Camera’s Motion”, the schedule will be set as continuous type, whole day and whole week. If not, the schedule is decided by settings of IP cameras. **So the schedule setting of motion detection on cameras must be done before if you don’t tick this option or**

you want to set detection for a certain time.

Step4: Check settings. Log in “Status”→“Event Status”, when something moves in the detected region, we will see the “” changing to “” .




Channel	Name	IP Address	Videoloss	Motion	IO
1	CAM1	192.168.8.170	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	CAM2		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	CAM3	192.168.8.103	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
4	CAM4		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	CAM5		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	CAM6		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	CAM7		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	CAM8		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	CAM9		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	CAM10		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
11	CAM11		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
12	CAM12		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
13	CAM13		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
14	CAM14		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
15	CAM15		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
16	CAM16		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
17	CAM17		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Figure 1.4 motion detection status in NVR Web

2) Way two--enable the motion detection via IP cameras

Step1: Log in web, and go to “Advanced Settings”→“Alarm”. Tick “Enable Alarm” and choose “Trigger Type” as “Motion Detection”.



Alarm Event

Enable Alarm:

Trigger Type: Motion Detection

Network Lost

Audio Alarm
(Please open the audio.)

External Input

Trigger Duration: 30 seconds

Figure 1.5 motion detection settings

Step2: Set the Motion Region and choose the sensitivity.




Figure 1.6 motion detection settings

Step3: Set the schedule for motion detection.




Figure 1.7 motion detection schedule

Step4: Check settings. After setting motion detection successfully, you will see the warning red spot on the live video page. **And when you log into NVR, you will see that the NVR updates its parameters with IP cameras automatically.**




Figure 1.8 motion detection

2. Recording Setting for Motion Detection (based on 1.)

After finishing 1., you can set recording for motion detection.

1) Local monitor setting of recording

Step1: Log in the local monitors, and go to “Record”→“Record model”, tick “Record by Schedule”. (Do not choose “Never” and “Always”, just check “By Schedule” if you want the camera to record only when motion is triggered)

Step2: Go to “Main Menu”→“Record”→“Record Schedule”, draw the time table to set the record schedule for motion detection, like the picture shown below.




Figure 2.1 Alarm record settings on NVR local monitor

Step3: Go to “Main Menu”→“Event”→“Motion Detection”, choose the camera channel that you already finished steps above, and tick channels you want to record in the column of “Trigger Channels Record”.



Figure 2.2 Alarm record settings on NVR local monitor

2) Web interface setting of recording

Step1: Log in NVR Web, go to “Settings”-> “Record”-> “Record model”, tick “Record by Schedule”. (Do not choose “Never” and “Always”, just check “By Schedule” if you want the camera to record only when motion is triggered)




Figure 2.3 Alarm record settings in NVR Web

Step2: Go to “Settings”→“Record”→“Record Schedule”, edit the time table to set the record schedule for motion detection, like the picture shown below.




Figure 2.4 Alarm record settings in NVR Web

Step3: Go to “Settings”→“Event”→“Motion Detection”→“Linkage Method”, choose the camera channel that you already finished steps above, and tick channels you want to record in the column of “Trigger Channels Record”.




Figure 2.5 Alarm record settings in NVR Web

3. Other Alarm Actions for Motion Detection (based on 1.)

After finishing 1., besides recording, there are other alarm actions for motion detection, like E-mail Linkage, Audible Warning and Alarm Output.

1) Local monitor setting of other alarm actions

Step1: Log in NVR local monitor, click “Event”→“Motion Detection”→“Edit”

Step2: Choose the effective time or draw the time table, select the alarm action and trigger interval. (This time table is used for setting the work time of other alarm action, not for recording, do not mix them up)




Figure 3.1 other alarm edition on NVR local monitor

2) Web interface setting of other alarm actions

Step1: Log in NVR Web, click “Settings”→“Event”→“Motion Detection”, click “Action Schedule”, edit the schedule time. (This time table is used for setting the work time of other alarm action, not for recording, do not mix them up)




Figure 3.2 other alarm edition in NVR Web

Step2: Turn to another tab, “Linkage Method”, select other alarm actions and trigger interval.

Motion Detection

Channel No.

Sensitivity

Enable IPC's Motion

[Area Settings](#) [Action Schedule](#) [Linkage Method](#)

Normal Linkage

Audible Warning

Email Linkage

Trigger Interval

Trigger Channels Record

Select All

1 2 3 4 5 6 7 8

[Copy to Camera](#)

Figure 3.3 other alarm edition in NVR Web